### **Testing Parallel Optics**

David Kuan (MSc, PMP)

Regional Product Manager – APAC

Viavi Solutions





# Agenda

- Basics
  - Why parallel optics with multi-fiber push-on/pull-off (MPO) connectors?
  - System architectures
  - Standards
  - Technology overview
- Test and Certification
  - End-face inspection and certification
  - Polarity check
  - Tier 1 (basic) certification
  - Tier 2 (enhanced) certification
  - Troubleshooting
- Wrap up





#### Is MPO New?





No – MPO connectors and ribbon fiber have been around for well over a decade






## What's Changed?

 Relentless need for speed

 MPO being extended to equipment



Courtesy of Leviton







### 40/100GE Client Interfaces Available

Interface/Application	Reach	Medium	Parallelism	Standard
100GBASE-ER4	40 km	SMF	4λ/dir	IEEE 802.3ba
ER4-Lite	20-25km	SMF	4λ/dir	Variation on 802.3ba
100GBASE-LR4	10 km	SMF	4λ/dir	IEEE 802.3ba
CWDM4	2 km	SMF	4λ/dir	CWDM4 MSA
CLR4	2 km	SMF	4λ/dir	CLR4 Alliance
PSM4	500 m	SMF	4 fibers / dir	PSM4 MSA
SWDM4	100 m	OM5 MMF	4 λ / dir	SWDM Alliance
40GBASE-SR4	100 m	OM4 MMF	4 fibers / dir	IEEE 802.3bj
100GBASE-SR4	70 m	OM4 MMF	4 fibers / dir	IEEE 802.3bm






#### Tests Defined in Standards


- Both TIA(526-14-C-2015,568.3), and ISO/IEC (61280-4x) standards specify to tiers of certification
  - Tier 1 (or basic): loss, length, and polarity
  - Tier 2 (or extended): Optical time domain reflectometer (OTDR)
- Tier 2 (extended) tests are an optional addition to tier 1 (basic) tests
- Fiber end-face inspection and certification is also a requirement to ensure pristine end-face condition PRIOR to mating




#### Data Center Examples of MPO/Ribbon Fiber



# Single Fiber vs. Multi-Fiber Connectors













# **Polarity and Gender**









## **MPO Patch Cord Configurations**

Table 2 - Type-A:1-1 array patch cord and array cable fiber sequence

Near / Far End		(vie	wing t	he arr		iber se			ace wi	th key	up)	
Near	1	2	3	4	5	6	7	8	9	10	11	12
Far	1	2	3	4	5	6	7	8	9	10	11	12



Figure 7 - Type-A:1-1 array patch cord and array cable (key-up to key-dov

Table 4 - Type-B:1-1 array patch cord and array cable fiber sequence

Near / Far End		(vie	wing t	he arr			equenc or plug		ace wi	th key	up)	
Near	1	2	3	4	5	6	7	8	9	10	11	12
Far	12	11	10	9	8	7	6	5	4	3	2	1





Figure 9 - Type-B:1-1 array patch cord and array cable (key-up to key-up)








#### **Focused on the Connection**



# **Top-View Cross Section of 12 Fiber**













# **Top-View Cross Section of 12 Fiber MPO**



#### Impact of MPO contamination

If a critical connection is affected, the impact can be exponential












#### **Test and Certification**








## **Test Challenges for MPO**

- End-face condition at ALL connection points
- When to test MPO vs. duplex/simplex
- Fiber map (polarity)
- Gender (pinned/unpinned) and its impact on reference methods and types of cables
- QSFP to LC connections
- Loss test vs. OTDR test






#### Data Center Examples of MPO/Ribbon Fiber Testing




#### **Inspect Before You Connect**<sup>sm</sup>

Follow this simple "INSPECT BEFORE YOU CONNECT" process to ensure fiber end faces are clean prior to mating connectors.



# Inspect ALL fibers in a Multi-Fiber Connector






Patch cords are easy to access and view compared to the fiber inside the bulkhead, which is frequently overlooked. The bulkhead side may only be half of the connection, but it is <u>far more likely to be dirty</u> and problematic.





#### **IEC 61300-3-35 Sets Requirements for Connector Quality**



Even for MPO!

ZONE	NAME (Diameter)	SCRATCHES	DEFECTS
A.	CORE Zone (0–65µm)	no limit <= 5μm 0 > 5μm	4 <= 5μm none > 5μm
В.	CLADDING Zone (65–115μm)	no limit <= 5μm 0 > 5μm	no limit < 2μm 5 from 2–5μm none > 5μm






# **Polarity Check (AKA Fiber Map)**

 For existing installations, the end-to-end polarity is often not known

 Polarity Check tool shows the polarity of the system











#### MPO to MPO Tier 1 Certification

- Test MPO Links and Channels
- Loss, length and polarity





de	fault					<del>15:3</del> 3
∌€	Limit	<b>1.9</b> dB				
Pol.	Fib.	Margin	Loss	Fib.	Margin	Loss
	1	0.82	1.08	7	0.92	0.98
<b>Z</b>	2	0.58	1.32	8	0.84	1.06
1310	3	0.51	1.39	9	0.58	1.32
	4	0.50	1.40	10	1.06	0.84
Z	5	0.97	0.93	11	1.12	0.78
1550	6	0.95	0.95	12	0.87	1.03





#### **MPO Power Meter**

MPO power meter – Using any MPO source

Fault Isolation

Testing output power from






Limit 1.90 dB  Channels Absolute Loss 1 -3.60 0.20 2 -3.70 0.05 3 -3.25 0.10
1 -3.60 0.20 2 -3.70 0.05
2 -3.70 0.05
3 -3.25 0.10
4 -3.30 0.10
5 -3.40 0.00
6 -3.30 0.10
7 -3.30 0.00
8 -3.20 0.00
9 -3.15 0.05
10 -3.05 0.05
11 -2.85 0.05
12 -2.95 0.00

## **Tier 2 Testing of MPO**

- Tier 1 testing cannot ensure individual event (splices and connection) losses are within spec OR the cable attenuation is uniform
- Tier 2 (OTDR) testing adds the characterization of these events to the certification test
- Tier 2 testing is also the ideal fiber trouble shooting tool to find the cause AND location of excess loss (incl. breaks) and reflectance
- Requires MPO switch
- Pinned/unpinned systems require different launch and receive cords



#### Schematic test results (pass example)








#### **Identify Front and Back Connectors**

- Conventional OTDRs can't distinguish between front and back connectors of a cassette
  - If ribbon connector (back) is damaged/dirty, maintenance of the connector/replacement can affect multiple fibers/services (up to 10 other channels)
  - If front connector (single) is damaged/dirty, maintenance of the connector/ replacement will affect only one fiber/ channel.
- High resolution OTDR's
  - Quickly identify if the issues is at the front or back connector avoiding unnecessary service/traffic disruption







### Wrap Up

- MPO end-face condition is the most critical element in a channel with MPO connections
- Polarity can be a challenge especially when adapting existing MPO backbones to new services
- Be aware of pinned/unpinned presents challenges for testing (test cords must mate with system – challenges with test device and test cord gender)
- Loss testing is typically done on links
  - 1/10G MM, 1/10/40/100G SM link is duplex
  - 40/100G MM, PSM4 SM link is MPO
- Testing channels may make sense if hydra (fan cables) are used
- OTDR testing of MPO allows:
  - Characterization of the link or channel (uniformity of cable attenuation and connection loss)
  - Fault isolation to prevent unnecessary service interruptions





### **Thank You**







**Technology Leadership** 

**Fast Technician Workflows** 

**Best Value** 

www.viavisolutions.com/enterprisetest





